

# Printer Compatibility List

Here is a list of printers that can work with the network enclosure

Epson						
ActionLaser 1100	EPL-5900PS	LP-8200C	PictureMate Delux	PM 730C	Stylus Color 800	Stylus Photo 750
ActionLaser II	EPL-6100	LP-8300C	SQ 1170	PM 740C	Stylus Color 850	Stylus Photo 780
ActionPrinter 3250	EPL-6100PS	LP-8300F	Stylus	PM 750C	Stylus Color 860	Stylus Photo 785
AcuLaser C1900	EPL-7100	LP-8400F	Stylus 800	Stylus C60	Stylus Color 880	Stylus Photo 790
AcuLaser C1900PS	EPL-N1600	LP-8500C	Stylus C 43 SX*	Stylus C61	Stylus Color 900	Stylus Photo 810
AcuLaser C2000	EPL-N1600PS	LP-8600	Stylus C20	Stylus C62	Stylus Color 980	Stylus Photo 820
AcuLaser C2000PS	EPL-N2050	LP-8600F	Stylus C20SX	Stylus C70	Stylus CX3900*	Stylus Photo 825
AcuLaser C4000	EPL-N2050+	LP-8700	Stylus C20UX	Stylus C70 plus*	Stylus CX4900*	Stylus Photo 830
AcuLaser C4000PS	EPL-N2050PS	LP-8800C	Stylus C40	Stylus C80	Stylus CX5200	Stylus Photo 830U*
AcuLaser C4100	EPL-N2050PS+	LP-8900	Stylus C40SX	Stylus C82	Stylus Color	Stylus Photo 870
AcuLaser C4100PS	EPL-N2120	LP-9000B	PM 760C	Stylus CX1500	Stylus Color 8 3	Stylus Photo 875
AcuLaser C8500	EPL-N2500	LP-9000C	PM 770C	Stylus CX3100	Stylus Color 400	Stylus Photo 890
AcuLaser C8500PS	EPL-N2500PS	LP-9100	PM 780C	Stylus CX3200	Stylus Color 440	Stylus Photo 895
AcuLaser C8600	EPL-N2750	LP-9200B	PM 790PT	Stylus C40UX	Stylus Color 460	Stylus Photo 900
AcuLaser C8600PS	EPL-N2750PS	LP-9200C	PM 800C	Stylus C41	Stylus Color 480	Stylus Photo 915
AcuLaser C9100	ESC/P Dot Matrix F	LP-9300	PM 820C	Stylus C41SX	Stylus Color 500	Stylus Photo 925
C88+*	L-1000	LP-9400	PM 850PT	Stylus C41UX	Stylus Color 580	Stylus Photo 935
CL 700	LP 8000	LP-9500C	PM 880C	Stylus C42	Stylus Color 600	Stylus Photo 1200
CL 750	LP-1800	LP-9600	PM 2000C	Stylus C42SX	Stylus Color 640	Stylus Photo 1270
Dot Matrix	LP-1900	LP-9600S	PM 2200C	Stylus C42UX	Stylus Color 660	Stylus Photo 1280
E 100	LP-2000	LP-9800C	PM 3000C	Stylus C43	Stylus Color 670	Stylus Photo 1290
EM 900C	LP-2200	LP-S4500	PM 3300C	Stylus C43SX	Stylus Color 680	Stylus Photo 1290S
EM 900CN	LP-2400	LP-S6500	PM 3500C	Stylus C43UX	Stylus Color 1160	Stylus Photo EX
EM 930C	LP-2500	LP-xx00	PM 3700C	Stylus C44	Stylus Color 1500	Stylus Photo EX3
EM 930CN	LP-3000	LQ-24	PM 7000C	Stylus C44SX	Stylus Color 1520	Stylus Pro 7000
EPL-5200	LP-3000C	LQ-500	PictureMate	Stylus C44UX	Stylus Color 3000	Stylus Pro 7500
EPL-5200+	LP-7000	LQ-550*	MC 7000	Stylus C45	Stylus Color I	Stylus Scan 2000
EPL-5700PS	LP-7000G	LQ-570+	MJ 930C	Stylus C46	Stylus Color PRO	Stylus Scan 2500
EPL-5800	LP-7500	LQ-850	MJ 6000C	Stylus C48	Stylus D78*	c146001*
EPL-5800PS	LP-7700	LQ-1050*	MJ 8000C	Stylus Color 740	Stylus DX4050*	d68*
EPL-5900	LP-7900	LQ-1170*	MachJet	Stylus Color 740 i*	Stylus Photo	gt 7000*

EPL-5900L	LP-8000C	LQ-2550	P 950A*	Stylus Color 760	Stylus Photo 700	
EPL-5900P*	LP-8100	LX-1050	PM 700C	Stylus Color 777	Stylus Photo 720	

## HP

2000C		DesignJet ColorPro	DeskJet 880C	DeskJet 9600	LaserJet 2430	PSC 370	PhotoSmart 8700
2500C		DeskJet	DeskJet 882C	DeskJet 9800	LaserJet 3050	PSC 380	PhotoSmart A310
2500CM		DeskJet 200	DeskJet 890C	DeskJet F370*	LaserJet 3052	PSC 500	PhotoSmart A430
2563		DeskJet 310	DeskJet 895C	DeskJet Plus	LaserJet 3055	PSC 750	PhotoSmart A510
Business Inkjet 1000		DeskJet 320	DeskJet 916C	DeskJet Portable	LaserJet 3300 MFP	PSC 750xi	PhotoSmart A610
Business Inkjet 1100		DeskJet 340C	DeskJet 920C	Deskjet D1360*	LaserJet 3310 MFP	PSC 1500	PhotoSmart A710
Business Inkjet 1200		DeskJet 400	DeskJet 948C	DeskJet 930C	LaserJet 3320 MFP	PSC 1510	PhotoSmart C3100
Business Inkjet 2200		DeskJet 450	DeskJet 950C	DeskJet 932C	LaserJet 3320N MFP	PSC 1600	PhotoSmart C3180*
Business Inkjet 2230		DeskJet 460	DeskJet 952C	DeskJet 933C	LaserJet 3390	PSC 2110	PhotoSmart C4100
Business Inkjet 2250		DeskJet 500	DeskJet 955C	DeskJet 934C	LaserJet 3392	PSC 2150	PhotoSmart C5100
Business Inkjet 2250TN		DeskJet 500C	DeskJet 957C	DeskJet 935C	LaserJet 4000	PSC 2170	PhotoSmart C5180*
Business Inkjet 2280		DeskJet 505J Plus	DeskJet 959C	DeskJet 940C	LaserJet 4050	PSC 2175	PhotoSmart C6100
Business Inkjet 2300		DeskJet 510	DeskJet 960C	Deskjet D2360*	LaserJet 4100	PSC 2210	PhotoSmart C7100
Business Inkjet 2600		DeskJet 540C	DeskJet 970C	HL-5050*	LaserJet 4200	PSC 2300	PhotoSmart D5060
Business Inkjet 2800		DeskJet 550C	DeskJet 975C	LaserJet	LaserJet 4240	PSC 2350	PhotoSmart D5100
Business Inkjet 3000		DeskJet 600	DeskJet 980C	LaserJet 2	LaserJet 4250	PSC 2355*	PhotoSmart D5160*
Color Inkjet Printer CP1160		DeskJet 610C	DeskJet 990C	LaserJet 2 w/PS	LaserJet 4300	PSC 2400	PhotoSmart D6100
Color Inkjet Printer CP1700		DeskJet 610CL	DeskJet 995C	LaserJet 2P	LaserJet 4345 mfp	PSC 2410*	PhotoSmart D7100
Color LaserJet 5		DeskJet 612C	DeskJet 1000C	LaserJet 2P Plus	LaserJet 4350	PSC 2410v*	PhotoSmart D7300
Color LaserJet 5M		DeskJet 630C	DeskJet 1100C	LaserJet 3	LaserJet 5000	PSC 2500	PhotoSmart P100
Color LaserJet 2500		DeskJet 632C	DeskJet 1120C	LaserJet 3D	LaserJet 5100	PSC 2510 photosma	PhotoSmart P130
Color LaserJet 2550		DeskJet 640C	DeskJet 1125C	LaserJet 3P w/ PC	LaserJet 5200	PaintJet	PhotoSmart P230
Color LaserJet 2550L*		DeskJet 648C	DeskJet 1180C*	LaserJet 3P w/PS	LaserJet 5200L	PaintJet XL	PhotoSmart P1000
Color LaserJet 2605		DeskJet 656C	DeskJet 1200C	LaserJet 4	LaserJet 8000	PaintJet XL300	PhotoSmart P1100
Color LaserJet 2700		DeskJet 660C	DeskJet 1220C	LaserJet 4 Plus	LaserJet 8100	PhotoSmart 140	PhotoSmart P1115
Color LaserJet 2800		DeskJet 670C	DeskJet 1280	LaserJet 4L	LaserJet 8150	PhotoSmart 240	PhotoSmart P1215
Color LaserJet 3000		DeskJet 670TV	DeskJet 1600C	LaserJet 4M	LaserJet 9000	PhotoSmart 320	PhotoSmart P1218
Color LaserJet 3500		DeskJet 672C	DeskJet 1600CM	LaserJet 4M Plus*	LaserJet 9000 MFP	PhotoSmart 330	PhotoSmart P1315
Color LaserJet 3550		DeskJet 680C	DeskJet 3547*	LaserJet 4ML	LaserJet 9040	PhotoSmart 370	PhotoSmart Pro B8300
Color LaserJet 3600		DeskJet 682C	DeskJet 3810	LaserJet 4MP*	LaserJet 9040 MFP	PhotoSmart 380	designjet 3800*
Color LaserJet 3700		DeskJet 690C	DeskJet 3816	LaserJet 4P	LaserJet 9050	PhotoSmart 420	e-printer e20
Color LaserJet 3800		DeskJet 692C	DeskJet 3820	LaserJet 4Si	LaserJet 9050 MFP	PhotoSmart 470	
Color LaserJet 4500		DeskJet 693C	DeskJet 3822	LaserJet 4V	LaserJet 9055 MFP	PhotoSmart 2570	

Color LaserJet 4550	DeskJet 694C	DeskJet 5150	LaserJet 4V/4LJ F	LaserJet 9065 MFP	PhotoSmart 2575*	
Color LaserJet 4600	DeskJet 695C	DeskJet 5158	LaserJet 5	LaserJet D1320*	PhotoSmart 2600	
Color LaserJet 4610	DeskJet 697C	DeskJet 5160	LaserJet 5L	LaserJet M3027 MFP	PhotoSmart 2700	
Color LaserJet 4650	DeskJet 710C	DeskJet 5440	LaserJet 5M	LaserJet M3035 MFP	PhotoSmart 3100	
Color LaserJet 4700	DeskJet 712C	DeskJet 5550	LaserJet 5MP	LaserJet M4345 MFP	PhotoSmart 3140*	
Color LaserJet 4730 MFP	DeskJet 720C	DeskJet 5550C*	LaserJet 5P	LaserJet M5025 MFP	PhotoSmart 3200	
Color LaserJet 5000	DeskJet 722C	DeskJet 5551	LaserJet 5Si	LaserJet M5035 MFP	PhotoSmart 3300	
Color LaserJet 5500	DeskJet 810C	DeskJet 5650	LaserJet 6	LaserJet P2015	PhotoSmart 3310*	
Color LaserJet 5550	DeskJet 812C	DeskJet 5652	LaserJet 6L	LaserJet P3004	PhotoSmart 7150	
Color LaserJet 8500	DeskJet 815C	DeskJet 5670	LaserJet 6MP	LaserJet P3005	PhotoSmart 7260	
Color LaserJet 8550GN	DeskJet 816C	DeskJet 5740	LaserJet 6P	LaserJet Plus	PhotoSmart 7268	
Color LaserJet 9500	DeskJet 820C	DeskJet 5850	LaserJet 1022	Mopier 240	PhotoSmart 7345	
Color LaserJet CM1015	DeskJet 825C	DeskJet 5940	LaserJet 1100	Mopier 320	PhotoSmart 7350	
Color LaserJet CM1017	DeskJet 830C	DeskJet 6122	LaserJet 1100A	OfficeJet J5700	PhotoSmart 7400	
Color LaserJet CP4005	DeskJet 832C	DeskJet 6127	LaserJet 1160	OfficeJet Pro K550	PhotoSmart 7550	
Color deskjet 3500*	DeskJet 840C	DeskJet 6520	LaserJet 1200	OfficeJet Pro K850	PhotoSmart 7660	
ColorLaserJet 9500 MFP	DeskJet 841C	DeskJet 6540	LaserJet 1220	OfficeJet Pro K5300	PhotoSmart 7760	
DesignJet 230	DeskJet 842C	DeskJet 6600	LaserJet 2100	OfficeJet Pro K5400	PhotoSmart 7800	
DesignJet 430	DeskJet 843C	DeskJet 6800	LaserJet 2100M	OfficeJet Pro L7300	PhotoSmart 7960	
DesignJet 700	DeskJet 845C	DeskJet 6840	LaserJet 2200	OfficeJet Pro L7500	PhotoSmart 8000	
DesignJet 2500CP	DeskJet 850C	DeskJet 6940	LaserJet 2300	OfficeJet Pro L7600	PhotoSmart 8100	
DesignJet 3500CP	DeskJet 855C	DeskJet 6980	LaserJet 2410	OfficeJet Pro L7700	PhotoSmart 8200	
DesignJet 5500ps	DeskJet 870C	DeskJet 9300	LaserJet 2420	PCL 6/PCL XL Printe	PhotoSmart 8400	

Canon					Apple
BJ-5	LBP-8A1	BJC-600	GP 405	PIXMA iP3300*	Dot Matrix
BJ-10e	LBP-8IV*	BJC-610	IR-C2620N*	PIXMA iP4000*	ImageWriter
BJ-10v	LBP-310	BJC-620	IR2200*	PIXMA iP4000r*	ImageWriter LQ
BJ-15v	LBP-320 Pro	BJC-680J	IR2870*	PIXMA iP4200*	LaserWriter 4/600
BJ-20	LBP-350	BJC-800	LBP-4+	PIXMA iP5000*	LaserWriter 12/640ps
BJ-30	LBP-430	BJC-880J	LBP-4U	PIXMA iP6600D*	LaserWriter 16/600
BJ-35v	LBP-470	BJC-4000	LBP-8*	PIXMA iP6700D*	LaserWriter IINTX
BJ-100	LBP-1000	BJC-4100	PIXMA MP510*	Pixma MP170*	LaserWriter IIG
BJ-200	LBP-1260	BJC-4200	PIXMA iP1000*	i70*	LaserWriter Pro 630
BJ-330	LBP-1760	BJC-4300	PIXMA iP1200*	iP4200 PIXMA *	LaserWriter Select 360
BJC-70	LBP-2900*	BJC-4300ex*	PIXMA iP1300*	iR 6800C*	Laserwriter 8500*
BJC-210	LBP5000*	BJC-4304*	PIXMA iP1500*	iR2020i*	

BJC-250	LIPS-II+	BJC-4400	PIXMA iP2000*				
BJC-250ex	LIPS-III	BJC-4550	PIXMA iP2200*				
BJC-255SP	LIPS-IV	GP 160*	PIXMA iP3000*				
BJC-265SP	LIPS-IVv	GP 335					

<b>Samsung</b>						
2250*	ML-1020	ML-1510	ML-5000a	ML-1750	ML-3050*	QL-5100A
CLP-300N*	ML-1200	ML-2151NPS	ML-5080	ML-2010	ML-3051N*	QL-6050
CLP-550*	ML-1210	ML-2152W	ML-6000	ML-2150	ML-3051ND*	SCX 4200*
CLP-550N*	ML-1220	ML-2152WPS	ML-6040	ML-2150PS	ML-3560*	SCX-4100*
CLP-550n*	ML-1250	ML-2510*	ML-2550	ML-2151N	ML-4500	SI-630A
ML-85	ML-1410	ML-2510 parallel w	ML-2551N	ML-6100	ML-4600	scx-5530fn*
ML-200	ML-1430	ML-1520	ML-2552W	ML-7000	ML-7050	
ML-210	ML-1440	ML-1610	ML-2570N*	ML-7000N	ML-7050 PS*	
ML-1000	ML-1450	ML-1650	ML-1710	ML-7000P	ML-7300	
ML-1010	ML-1450PS	ML-1651N	ML-1740	ML-2571N*	ML-7300N	

<b>Toshiba</b>		<b>Fujitsu</b>		<b>IBM</b>	
E210*	e-Studio 351c		1200		3853 JetPrinter
FS-1010*	e-Studio 352		2400		4019
GL 1010	e-Studio 450		3400		C510*
GL 1020	e-Studio 451c		FMLBP2xx Page Printer		Execjet 4072
e-Studio 165	e-Studio 452		FMPR		
e-Studio 200L	e-Studio 520		PrintPartner 10V		
e-Studio 202L	e-Studio 600		PrintPartner 16DV		
e-Studio 205	e-Studio 720		PrintPartner 20W		
e-Studio 230	e-Studio 850		PrintPartner 8000		
e-Studio 232	e-Studio 2500c				
e-Studio 280	e-Studio 3500c		<b>NEC</b>		PinWriter P7
e-Studio 281c	e-Studio 3510c		MultiWriter		PinWriter P7 plus SuperScript 660i
e-Studio 282	e-Studio 3511		P2X		PinWriter P60 SuperScript 1400
e-Studio 350	e-Studio 4511		PC-PR150		PinWriter P70 SuperScript 1800
<b>Dell</b>			PC-PR201		Pinwriter P20 SuperScript 4600N
5100CN*			PC-PR1000		SilentWriter LC 890
AIO Printer A920*			PC-PR2000		Silentwriter 95f
BJC-2100*			PICTY180		Silentwriter 1097 / S102P*

M5200				PinWriter P*	Silentwriter2 S60P		
S2500				PinWriter P6	Silentwriter2 model 290		
				PinWriter P6 plus			

Lexmark		Lanier					
4039 10plus	Optra R+		2132				
BJC-2100*	Optra S 1250		2138	LD120d	LF510/515e	MP 1100/LD1100	
C510*	Optra S 1625*		2145	LD122	LP 020c	MP 1350/LD1135	
C522n*	Optra S 1855		5622	LD124c	LP 036c	MP 5500/LD255	
C532N*	Optra Se 3455		5627	LD127	LP025/LP026	MP 6500/LD265	
E120*	Optra T610		5632	LD132	LP025N/LP026N	MP 7500/LD275	
E120n*	Optra T612		5635	LD132c	LP031c	MP 9000/LD190	
E210	Optra T614		5645	LD135	LP032	MP C2500/LD425c	
E230*	Optra T616		LC155	LD145	LP116c	MP C3000/LD430c	
E232*	Optra W810		LD015	LD151	LP122c/LP121c	MP C3500/LD435c	
E342N*	T420*		LD024c	LD160	LP125cx/LP126cn	MP C4500/LD445c	
Optra C710	T430*		LD032c	LD160c	LP127n/LP128n	MPC1500/LD215c	
Optra Color 40	T520n*		LD035	LD175	LP128		
Optra Color 45	T640n*		LD045	LD225	LP135n		
Optra Color 120	Valuewriter 300		LD060	LD228c	LP138c		
Optra Color 127	X 4250*		LD075	LD230	LP145n/SP 8100DN		
Optra E	X852e*		LD090	LD232c	LP175/LP175hdn		
Optra E+	X1170*		LD0105	LD235	LP222cn/LP221c		
Optra E310	X1185*		LD115	LD238c	LP226c/SP C410		
Optra E312	Z52		LD116	LD245	LP231c/SP C411		
Optra E321	Z53		LD118	LD328c	LP235c		
Optra Ep	Z612*		LD118d	LD335c	LP332c		
Optra K 1220	x1150 PrintTrio*		LD120	LD345c	LP335c		
Optra Lx+*	x1270*						
Optra M410	x1290*						
Panasonic							
KX-P1123	KX-P4450						
KX-P1124	KX-P5400						
KX-P1150	KX-P7105*						
KX-P2023	KX-P8420						
KX-P2135	KX-P8475						

KX-P2150	KX-P4410						
----------	----------	--	--	--	--	--	--